

SPIDER-MAN 3

AGES 4+

69168/69113 Asst.


UNLEASHED 360°

SPIDER-MAN®

To assemble web:


1

Snap center post into plastic hub.




2

Insert center post through hole in back of web.




3

Push tips of web arms into holes around edge of web until they snap into place.



4

Turn and bend arms to pose web.



COLUMBIA PICTURES

© 2006 COLUMBIA PICTURES INDUSTRIES, INC. ALL RIGHTS RESERVED.

SPIDER-MAN

MERCHANDISING



VISIT

<http://www.hasbro.com/spiderman>



Not suitable for children under 3 years because of small parts — choking hazard.

Some poses may require hand support.

Spider-Man and all related characters and the distinctive likeness thereof: TM & © 2007 Marvel Characters, Inc. Spider-Man 3, the Movie: TM & © 2007 Columbia Pictures Industries, Inc. All rights reserved.

www.marvel.com

®* and/or TM* & © 2007 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks.

P/N: 6679630000